

Contribution ID : 157

Type : Contributed Oral

Gain stabilization of SiPMs

Content

The gain of SiPMs increases with bias voltage and decreases with temperature. To operate SiPMs at stable gain, the bias voltage can be adjusted to compensate temperature changes. We have tested this concept with 30 SiPMs from three manufacturers (Hamamatsu, KETEK, CPTA) in a climate chamber at CERN varying the temperature from 1°C to 50°C. We built an adaptive power supply that used a linear temperature dependence of the bias voltage readjustment. With one selected bias voltage readjustment, we stabilized four SiPMs simultaneously. We fulfilled our goal of limiting the deviation from gain stability in the 20°C-30°C temperature range to less than $\pm 0.5\%$ for most of the tested SiPMs.

Summary

Primary author(s) :Prof. EIGEN, Gerald (University of Bergen)Presenter(s) :Prof. EIGEN, Gerald (University of Bergen)Session Classification :Calorimetry

Track Classification : Calorimetry